


LÍNEA CALOR



Manual de despiece

PRP-5000

Horno convector turbo a gas, 5 niveles

LÍNEA CALOR

POSICIÓN	CÓDIGO SAP	CÓDIGO INTERNO	NOMBRE
1	-	103271100016R001	P27440 - CUERPO
2	-	103271100016R002	P28806 - MARCO
3	-	103271100016R003	CONTROLADOR DE TEMPERATURA 220V (PRP-5000) (DESCONTINUADO)
3.1	504627	103271100016R301	PANEL CONTROLADOR DE TEMPERATURA 220V (PRP-5000N)
3.3	504628	103271100016R303	CONTROLADOR DE TEMPERATURA 220V (NEGRO) INV-YB1-06-J-H-F (PRP-5000)
4	504574	103271100016R004	P14726 - QUEMADOR (PRP-5000)
5	506255	103271100016R005	SOPORTE BANDEJA DERECHA (PRP-5000)
6	505180	103271100016R006	SOPORTE BANDEJA IZQUIERDA (PRP-5000)
7	504575	103271100016R007	ASPA
8	504576	103271100016R008	MOTOR TURBO 1/4 CV 4 P 110_220V 50/60 HZ
9	504577	103271100016R009	P650 - PROTECCION ASPA
10	504578	103271100016R010	SELLADO LAMPARA (PRP-5000/PRP-8000)
11	504579	103271100016R011	PROTECTOR LAMPARA (PRP-5000/PRP-8000)
12	504580	103271100016R012	P27432 - FIJADOR LAMP (PRP-5000/PRP-8000)
13	504581	103271100016R013	P27466 - SOQUETE LAMPARA MOD ANTIGUO (PRP-5000/PRP-8000)
14	504582	103271100016R014	P28872 - LAMPARA HALOGENA 35W 12V MOD ANTIGUO (PRP-5000/PRP-8000)
14.1	504626	103271100016R141	SOQUETE LAMPARA 25W 220V (PRP-5000/PRP-8000)
15	-	103271100016R015	P30833 - BASE SUPERIOR
16	-	103271100016R016	P27406 - BASE EXTERIOR IZQUIERDA (PRP-5000/PRP-8000)
17	-	103271100016R017	P30832 - BASE TRASERA
19	504583	103271100016R019	MICRO LLAVE AH 715359 MB-35 (INTERRUPTOR PUERTA) (MV7G5FA1) (PRP-5000/PRP-8000)
20	504584	103271100016R020	P28378 - ALARMA (PRP-5000/PRP-8000)
21	-	103271100016R021	P30834 - BASE EXTERIOR DERECHA (PRP-5000/PRP-8000)
21.1	-	103271100016R211	TAPA PANEL CONTROL (PRP-5000)
22	-	103271100016R022	P27334 - BASE IZQUIERDA DE MOTOR
23	-	103271100016R023	P27335 - BASE DERECHA DE MOTOR
24	504585	103271100016R024	P909 - VÁLVULA SOLENOIDE AGUA 220V (PRP-5000/PRP-8000)
25	-	103271100016R025	P29190 - BASE INTERNA DERECHA
26	-	103271100016R026	P29749 - SOPORTE CAJA IGNITORA (PRP-5000/PRP-8000)
28	504586	103271100016R028	P8610/P33957 - CAJA IGNITORA 8HZ (PRP-5000)
29	504587	103271100016R029	TUBO DE COBRE SALIDA DE VAPOR COMPLETO (PRP-5000/PRP-8000)
30	504588	103271100016R030	P26800 - TUBO DE COBRE VAPOR COMPLETO (PRP-5000/PRP-8000)
31	504589	103271100016R031	P594 - MANGUERA P/ENTRADA DE AGUA 1,30MT (PRP-5000/PRP-8000)
34	-	103271100016R034	P29842 - MANGUERA ANTI FUEGO (3/8 X 100) (PRP-5000/PRP-8000)
35	-	103271100016R035	P123 - INYECTOR 1,1/1,0mm C/AD MANG (PRP-5000/PRP-8000)
36	-	103271100016R036	P148 - ABRAZADERA 12X16 (PRP-5000/PRP-8000)
37	504590	103271100016R037	P29530 - CABLE 3X1,5X1,65 C/PLUG 10A C/PREN (PRP-5000/PRP-8000)
38	504591	103271100016R038	P27463 - BURLETE 53X68CM (PRP-5000 STYLE)
38.1	504629	103271100016R381	BURLETE 51X67CM (PRP-5000N NEW LIGHT STYLE G2)
39	-	103271100016R039	BASE DE VENTILADOR (PRP-5000/PRP-8000)
40	504592	103271100016R040	P27524 - VIGA SUPERIOR
41	504593	103271100016R041	P20960 - PILAR
42	-	103271100016R042	P27521 - VIGA INFERIOR
43	504545	10327100002R002	P17519 - RUEDA TURBO 1/2"X1.3HPP CON FRENO (PR-634/PRP-5000)

POSICIÓN	CÓDIGO SAP	CÓDIGO INTERNO	NOMBRE
44	504546	10327100002R003	P871 - RUEDA TURBO GFREE 312P 1/2"X1.3HPP SIN FRENO (PR-634/PRP-5000)
45	-	103271100016R045	P26913 - CHICOTE ELÉCTRICO MOTOR (PRP-5000/PRP-8000)
46	-	103271100016R046	P26912 - CHICOTE ELÉCTRICO FAISCADOR (PRP-5000/PRP-8000)
47	-	103271100016R047	P7323 - TERMINAL PINO PI 2288 (WP 13015) (PRP-5000/PRP-8000)
48	504596	103271100016R048	P10082/P35189 - ELECTRODO DE ENCENDIDO (PRP-5000/PRP-8000)
49	-	103271100016R049	P28319 - CHICOTE ELÉCTRICO SENSOR (PRP-5000/PRP-8000)
50	-	-	-
51	-	103271100016R051	P29193 - ESQUINERO 842X293 (PRP-5000/PRP-8000)
52	-	-	-
53	-	-	-
54	-	-	-
55	-	-	-
56	-	-	-
57	-	-	-
58	-	-	-
59	-	-	-
60	-	103271100016R060	P28125 - BASE CONTACTOR (PRP-5000/PRP-8000)
61	504597	103271100016R061	P8169 - CONTACTOR CWO7-10 220V 50/60HZ (PRP-5000/PRP-8000)
62	-	103271100016R062	P20322 - CONMUTADOR 6AMP CURVA C
63	-	103271100016R063	P28320 - CHICOTE ELECTRICO TIERRA G (PRP-5000/PRP-8000)
64	-	103271100016R064	P29188 - CHICOTE ELECTRICO
65	-	103271100016R065	LATA INFERIOR
66	-	-	-
67	-	-	-
68	-	-	-
69	-	-	-
70	-	-	P31035 - PUERTA COMPLETA 60x78cm (PRP-5000)
71	504598	103271100016R071	VIDRIO PUERTA (PRP-5000)
7.1	504630	103271100016R711	-
72	-	-	P28894 - TRANSFORMADOR 220/110V 12V (PRP-5000/PRP-8000)
73	504599	103271100016R073	-
74	-	-	-
75	-	-	-
76	-	-	P30130 - BANDEJA (PRP-5000/PRP-8000)
77	-	103271100016R077	TERMOCLEMENTO (SONDA TEMPERATURA) T/J R 1/4 500MM
78	504600	103271100016R078	(PRP-5000/PRP-8000)
79	-	-	-
80	-	-	-
81	-	-	-
82	-	-	-
83	504601	103271100016R083	P14728 - TUBO DE COBRE PARA GAS COMPLETO (PRP-5000/PRP-8000)
84	-	-	-
85	504602	103271100016R085	P28491 - CUBIERTA DE MOTOR (PRP-5000)
86	506498	103271100016R086	BISAGRA SUPERIOR (PRP-5000)

Manual de despiece

PRP-5000

Horno convector turbo a gas, 5 niveles

LÍNEA CALOR

POSICIÓN	CÓDIGO SAP	CÓDIGO INTERNO	NOMBRE
87	-	103271100016R087	BUJE BISAGRA (PRP-5000)
88	-	-	-
89	-	-	-
90	-	-	-
91	-	-	-
92	-	-	-
93	-	-	-
94	-	-	-
95	-	-	-
96	-	-	-
97	-	-	-
98	-	-	-
99	-	-	-
100	-	-	-
101	-	-	-
102	-	-	-
103	-	-	-
104	-	-	-
105	-	-	-
106	-	-	-
107	-	-	-
108	-	-	-
109	-	-	-
110	-	-	-
111	-	-	-
112	-	-	-
113	-	103271100016R113	P31752 - HILO TIERRA C/TERMINAL CUADRADO (PRP-5000/PRP-8000)
115	504603	103271100016R115	P27494 - FUSIBLE 5A (PRP-5000/PRP-8000)
116	-	103271100016R116	DUCTO DE INYECTORES (PRP-5000)
117	504605	103271100016R117	P13213- ELECTROVÁLVULA DE GAS (PRP-5000/ PRP-8000)
118	504606	103271100016R118	P32920 - BURLETE 65X49CM (PRP-5000 MODELO ANTIGUO)
119	504607	103271100016R119	P35736 - INTERRUPTOR ON/OFF BIPOLAR ROJO PEQUEÑO 16A 250V
120	504608	103271100016R120	(PRP-5000/ PRP-8000)
121	-	-	KIT ILUMINACIÓN (PRP-5000 / PRP-8000)
122	504610	103271100016R122	-
123	-	-	PROTECCIÓN HÉLICE PRP-5000
124	504612	103271100016R124	-
125	504613	103271100016R125	TORNILLO C/ CABEZA LENTEJA 3/16 X 1/2
126	504614	103271100016R126	P1600 - ARANDELA ASBERIT
127	-	-	P925 - CONJUNTO HÉLICE (PRP-5000/PRP-8000)
128	504616	103271100016R128	-
129	-	-	CONTROLADOR PRP STYLE INV-12401
130	504617	103271100016R130	-
131	504618	103271100016R131	P33957 - TRANSFORMADOR DE CORRIENTE 4 PINES

POSICIÓN	CÓDIGO SAP	CÓDIGO INTERNO	NOMBRE
132	-	-	-
133	504620	103271100016R133	P36539 - CONJUNTO DE RUEDAS R1125 HR1 / 2X26SS CON PESTILLO
134	504621	103271100016R134	P36545 - CONJUNTO DE RUEDAS R1125 HR1 / 2X26S SIN PESTILLO
135	-	-	-
136	504623	103271100016R136	P34166 - TUB PRP-8000ST G2 RASE COMPLETA
137	504624	103271100016R137	DUCTO DE INYECTORES PRP5000 Y 8000
138	-	103271100016R138	INTERRUPTOR (MOTOR/LAMPARA)
139	504625	103271100016R139	CONTROLADOR DE TEMPERATURA (NEGRO) INV-YB4-01-JH-F (PRP-5000)
140	-	-	-
141	504135	103011100042R141	INTERRUPTOR ON/OFF BIPOLAR ROJO GRANDE (PRP-004/PRP-5000/PRP8000)